



SUPPLEMENTAL PROCEDURES

FINAL COCKPIT ASSEMBLY INSTRUCTIONS

- 1 TIGHTEN FRICTION NUT TO MAXIMUM FRICTION POSITION.
- 2 ADJUST FRONT NUT UNTIL IT IS LIGHTLY CONTACTING FRICTION NUT.
- 3 TIGHTEN BACK NUT AS SPECIFIED IN APPLICABLE RAYTHEON/BEECHCRAFT MAINTENANCE/SHOP MANUAL INSTRUCTIONS.



TITLE:
THROTTLE CABLE ASSY INSTALLATION